

LCD SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	LCDB Assy	DWX4166
2	TFT LCD	CWX4352
3	FFC	DDD1873
4	Ferrite Clamper	DTX1011
5	Dial Knob	DAA1246
6	Button	DAC3113
7	Button	DAC3118
8	Button	DAC3289
9	Button	DAC3290
10	Button	DAC3291
11	Button	DAC3292
12	Button	DAC3293
13	Button	DAC3412
14	Window	DAH3217
15	Packing/L	DEC3568
16	Packing/S	DEC3569
17	Stay	DNH3361
18	Shield Case	DNH3362
19	Panel	DNK6772
20	Screw	BBZ30P060FTB
21	Screw	BPZ26P080FTC



A

B

C

D

E

F