

# Connecting the BOSS TONE STUDIO for KATANA Gen3 Android App to the KATANA Unit

---

© 2024 Roland Corporation

01

For details on how to use BOSS TONE STUDIO, refer to the “Using BOSS TONE STUDIO for KATANA Gen3” (BOSS website).


1. Power-on the KATANA unit and the mobile device.
2. In your mobile device's settings, turn Bluetooth on.



### NOTE

Even if the "Available devices" list shows "KATANA 3 MIDI", don't tap it.

3. Start the "BOSS TONE STUDIO for KATANA Gen3" app that you installed in your mobile device.
4. Tap [Bluetooth MIDI DEVICE] that appears in the screen, and then tap "KATANA 3 MIDI".




Verify that "\*" is shown at the upper right of KATANA 3 MIDI.



\* If "KATANA 3 MIDI" is not shown, tap "SCAN" at the very bottom of the Bluetooth Devices screen, and search again.

**5.** Tap the Android back button to return to the previous screen.

**6.** Verify that "KATANA 3 MIDI" is shown for "CONNECT" area.



**7.** Tap [OK] to start communication.

## If you can't connect

Check each of the following five items one at a time.

- 1** Make sure that Bluetooth is enabled on the BOSS Bluetooth® Audio MIDI Dual Adaptor (BT-DUAL) that's connected to the KATANA

Verify that the BT-DUAL unit's Bluetooth indicator is blinking or lit.


If it is unlit, press the BT-DUAL pairing button to make it blink or light.

- 2** In step 2 of the procedure, could you have tapped a model name shown on the mobile device?

When you turn the Bluetooth switch on in step 2, "KATANA 3 MIDI" might appear in the list of "Available devices" but you should not tap it. If you tapped it, clear the pairing, and try the procedure again from step 1.

## Clearing the pairing

1. Tap the gear icon shown beside "KATANA 3 MIDI" in "Paired devices", and tap "Unpair".



2. Turn the Bluetooth switch off.



### **3 Turn Bluetooth on and off once again**

Turn Bluetooth on/off again.

### **4 Close all apps, and try the procedure again from [step 1](#)**

If you've checked **1–3** and still cannot connect to the app, close all apps that are running on your mobile device.

If the KATANA is paired, clear the pairing.

## **Closing the app**

Tap Android's multitask button, and swipe the app screen upward.

- \* The operation for closing an app will differ depending on the mobile device that you're using. Close the app using the appropriate operation for your mobile device.

### **5 Turn Android Location mode on**

### **6 Power-off the mobile device and the KATANA unit, and then power them on again**

If you've checked **1–5** and still cannot connect to the app, power-off the mobile device and the KATANA, wait for about 10 seconds, and power them on again.

If the KATANA is paired, clear the pairing.

If you've checked **1–6** and still cannot connect to the app, contact your dealer or a Roland support.